



Email: solutions@tome.com
ABN 80502190351

DELICA WINDOW BOLT PROTECTORS

Fitting - You will need:

A hair dryer or hot air gun.

A rag.

Something to clean the windows with.

A reasonably stiff bristled brush.

Application takes approximately 10 minutes for all 3 windows.

4 stickers are included in case you stuff one up.

- Make sure the nuts and bolts are done up nice and tight before you begin.
- Thoroughly clean the outside window bolts and surrounding areas.
- Allow to dry completely.
- Peel off one sticker.
- Stick top edge of sticker approximately 1 cm above the window bolt and press down smoothing out to each side with your fingers or a rag.
- Holding the top edge down stretch the sticker down over the window bolt and press the bottom two corners down trying to keep the side edges straight.
- Smooth down the two side edges leaving the bottom edge sticking up and likely with a bow in the middle pointing down. This bow allows air to escape when finishing off the sticker.
- Apply heat gently to the sticker and begin to work the plastic into the grooves at the top and sides (using the brush here helps, use a stippling action).
- Use your fingers or rag to work both sides down and around the bottom of the nut taking care to try to avoid a seam forming if possible (difficult but not impossible).
- Apply a little more heat and work the plastic into all the gaps and using the back of your fingernail work any air bubbles out to the sides of the plastic.
- Smooth all over firmly with the rag.
- Move onto the next window.

PM me any of your questions. Your feedback is always appreciated.

Cheers,
Tom